

Dialock Terminals V7 - Statusmeldungen

Rote LED	Grüne / Blaue LED	Status	Bemerkung
abwechselndes Blinken (+ 3x piepsen)		Batterie leer	1. Stufe der Batteriewarnung
blinken 3x gleichzeitig		Terminal blockiert	Terminal daueroffen oder dauergeschlossen
blinken 8x abwechselnd		Uhr nicht gestellt	Nur für Lockerlock ISO
blinkt	aus	Terminal blockiert	Personnel Key hat keine zeitliche Berechtigung
ein	blinkt 3x	„Bitte nicht stören“ ist aktiv	
ein	ein	Cash Buchung	Cash Buchung ist aktiv
ein	blinkt 2x	Cash Fehler	Nicht genügend Guthaben auf Key
ein Geht 2x aus	ein	Cash Fehler	Cashwert passt nicht zum System
abwechselndes Blinken (+ 6x piepsen)		Terminal blockiert	2. Stufe der Batteriewarnung; Terminal ist nun blockiert
abwechselndes Blinken (für ca. 5s)			Erwarten nächsten Key beim 4-Augen-Prinzip
ein (geht kurz aus)	aus	Terminal blockiert	Zeitblockade
blinkt 3x	aus	Terminal Fehler	Speicher voll
blinkt 4x	aus	Terminal Fehler	Fehler in Transponderschnittstelle (kein Transpondersystem detektiert)
blinkt 5x	aus	Terminal Fehler	Fehler in Transponderschnittstelle
blinkt (0,5 Hz)	ein	Terminal Fehler	Lesemodul Wandterminal – EEPROM Fehler
abwechselndes Blinken (grüne LED blinkt kurz)		Terminal Fehler	Steuerung Wandterminal – keine Kommunikation mit Lesemodul oder Lesemodul falsch adressiert
blinken mehrfach gleichzeitig		Terminal Fehler	LEGIC System: Taufe erforderlich
beide an (0,3s) Rot an (0,3s) beide aus (0,3s)		Terminal Fehler	Lesemodul Wandterminal – Taufe erforderlich
blinken gleichzeitig schnell		Terminal beschäftigt	Total Reset
blinken 10x abwechselnd und piepst schnell		Terminal Fehler	Internes EEPROM kann nicht geschrieben werden (evtl. komplett leere Batterien)
blinken 4x		Terminal Fehler	DFT V2: Fehler in Echtzeituhr
ein (+ 5x piepsen)	aus	Terminal Fehler	DT /DTSH V2: Kupplungsfehler, Terminal kuppelt nicht ein
Aus	Ein (5x piepsen)	Terminal Fehler	DT /DTSH V2: Kupplungsfehler, Terminal kuppelt nicht ein
blinken gleichzeitig und piepsen 4x schnell			DT Lite: keine Lizenz für Dialock Betriebsart

Stand: 15.04.2010

Dialock Terminals V7 – Status report

Red LED	Green / Blue LED	Status	Remark
alternating flashing (+ 3x beeps)		Battery empty	1st level of Battery warning
flashing 3x simultaneously		Terminal blocked	Terminal permanently open or permanently closed
flashing 8x alternating		Clock not set	Only for Lockerlock ISO
flashes	off	Terminal blocked	Personnel Key has no time authorization
on	flashes 3x	„Do not disturb“ is active	
on	on	Cash Booking	Cash Booking is active
on	flashes 2x	Cash error	Not enough credit on key
on turns off 2x	on	Cash error	Cash value does not fit the system
alternating flashing (+ 6x beeps)		Terminal blocked	2nd level of battery warning; terminal is now blocked
alternating flashing (for approx. 5s)			Expect the next key with the 4-eyes principle
on (turns off briefly)	off	Terminal blocked	Time blockade
flashes 3x	off	Terminal error	Memory full
flashes 4x	off	Terminal error	Error in transponder interface (no transponder system detected)
flashes 5x	off	Terminal error	Error in transponder interface
flashes (0,5 Hz)	on	Terminal error	Wall terminal reader module – EEPROM error
alternating flashing (green LED flashes briefly)		Terminal error	Wall terminal control unit - no communication with reader module or reader module incorrectly addressed
flashing several times simultaneously		Terminal error	LEGIC system: Initiation required
both on (0,3s) red on (0,3s) both off (0,3s)		Terminal error	Wall terminal reader module – Initiation required
flashing quickly simultaneously		Terminal busy	Total Reset
flashing 10x alternating and beeps quickly		Terminal error	Internal EEPROM cannot be written (possibly completely empty batteries)
flashing 4x		Terminal error	DFT V2: Error in real-time clock
on (+ 5x beeps)	off	Terminal error	DT /DTSH V2: Clutch error, terminal does not engage
off	on (5x beeps)	Terminal error	DT /DTSH V2: Clutch error, terminal does not engage
flashing simultaneously and beep 4x quickly			DT Lite: no license for Dialock operating mode

Status: 04/15/2010